

## **Basis of Bearing**

The bearing along this line is the basis for all other bearings listed on this survey. This bearing relates directly to the "City of Idaho Falls Coordinate System of 2004". Which is derived from the Idaho State Plane Coordinate System (East Zone 1101) US survey feet and using a combined scale factor of 1.000277265 for a grid to ground conversion, (reference frame NAD\_83(2011), epoch 2010.0000). The system orientation is based on grid north along the East Zone central meridian. No convergence angle has been applied.